

PACKAGING PROCEDURES FOR MEDICAL WASTE DISPOSAL

Using Stericycle Corrugated Containers

STEP 1



SET UP BOX

- Turn over and seal bottom flaps with tape
- Auto-locking boxes, engage bottom flaps

STEP 2



LINE BOX WITH RED BAG

STEP 3



TIE BAG WHEN BOX IS FULL

STEP 4



SEAL TOP OF BOX

- Seal with tape
- Auto-locking boxes, engage top flaps

STEP 5



CHECK MARKINGS

- Federal markings (see picture above)
- Additional state regulations may apply, see Stericycle representative
- Apply bar code label where available

UNACCEPTABLE



Stericycle®
Protecting People. Reducing Risk.™

REGULATORY REQUIREMENTS

GENERAL

- Generators are responsible for packaging their wastes.
- Each bag must be hand tied by gathering and twisting the neck of the bag and using a tie or hand knot to secure the bag, and each container must be securely closed.
- Closed bags must not be visible once secondary container is closed.
- Improperly packaged containers or damaged containers will be denied pick-up or returned to the generator.
- Only Regulated Medical Waste can be placed in Stericycle containers.

SHARPS

- Sharp materials ("sharps") must be placed in a puncture-resistant container designed for "sharps" waste. "Sharps" include needles, syringes, broken glass, scalpels, culture slides, culture dishes, broken capillary tubes, broken rigid plastic and exposed ends of dental wires.
- All sharps containers should be properly closed before being placed into secondary containers.
- No loose sharps are permitted outside of sharps containers

For information, contact your Stericycle Sales Representative or Customer Service at (866) 783-7422.